

- 1 NON-FASTENING DETAIL
- (2) FASTENING DETAIL
- (3) INSIDE CORNER DETAIL
- (4) FORMED CORNER DETAIL
- (5) FLUSH TERMINATION DETAIL
- 6 CORNER TERMINATION DETAIL
- (7) BASE DETAIL
- (8) MCM PARAPET CAP DETAIL
- 8A) PARAPET CAP FLASHING DETAIL
- 9 SOFFIT RETURN DETAIL
- (10) WINDOW HEAD DETAIL

- 11) WINDOW HEAD DETAIL
- (12) WINDOW SILL DETAIL
- (13) WINDOW JAMB DETAIL
- VIIIVDOVV O/NIND DE I/NIE

TERMINATION DETAIL


- (15) COLUMN SECTION



System 1400
<u>ISOMETRIC VIEW</u>
Standard Details 11/05/15


ALUMAWALL INC., Telephone: 408-292-6353 FAX: 408-275-6225 Website: www.alumawall.com












2

System 1400


TYPICAL FASTENING DETAIL
Scale: Full














System 1400

FORMED CORNER PANEL RETURN DETAIL

Scale: Full

ALUMAWALL INC., Telephone: 408-292-6353 FAX: 408-275-6225 Website: www.alumawall.com








System 1400


FLUSH TERMINATION DETAIL
Scale: Full




























8


System 1400

MCM PARAPET CAP DETAIL
Scale: Full










(11)

System 1400
WINDOW HEAD DETAIL
Scale: Full






12

System 1400
WINDOW SILL DETAIL
Scale: Full







(13)


System 1400
WINDOW JAMB DETAIL
Scale: Full











System 1400
COLUMN SECTION
Scale: Full

ALUMAWALL INC., Telephone: 408-292-6353 FAX: 408-275-6225 Website: www.alumawall.com